



VIEWED FROM INSIDE CAB

5/16" mount holes (typ. 8)

FOR INSTALLATION BY TRAINED PROFESSIONALS ONLY

DO NOT COMPRESS GASKET TO LESS THAN 1/4"
A THREADLOCKER LIKE LOCTITE® 262 MAY BE USED

CONDENSATE DRAIN NIPPLE SHOULD BE LEVEL OR BE ON LOWER SIDE
DRAIN HOSE AND DRAIN HOSE CHECK VALVE (RUBBER DUCKBILL) MUST BE USED
ENSURE DRAIN HOSE DOES NOT RUN HIGHER THAN LEVEL OF DRAIN PAN
CHECK VALVE ON DRAIN HOSE MUST FACE DOWN BELOW ROOF LEVEL

INITIAL CHARGE SHOULD BE 34 OZ. FOR HOSE KITS TO 4'
WEIGH YOUR CHARGE AND WRITE IT ON THE SERIAL NUMBER PLATE PROVIDED

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
VISIONAIRE, INC. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
VISIONAIRE, INC. IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:		NAME	DATE
DRAWN			
CHECKED			
ENG APPR			
MFG APPR			
QA			
INTERPRET GEOMETRIC TOLERANCING PER DATASHEET		COMMENTS	
NEXT ASSY	USED ON	FINISH	
APPLICATION			

VISIONAIRE, INC.		
TITLE: MOUNTING TEMPLATE FOR 29-7000 AIR CONDITIONER		
SIZE: DWG. NO.	REV	
D 29-7000 TEMPLATE		
SCALE: 1:1	WEIGHT:	SHEET: 0F 1

DWG-1500 WITH 100-4-ET0