

VISIONAIRE 7100 SERIES INSTALATION KIT

36-7100-602 - BOLT KIT

4EA. 5/16" X 2" GRADE 5 BOLT

4EA. 5/16" X 1" GRADE 5 BOLT

4EA. 5/16" LOCK WASHER

4EA. 5/16" FLAT WASHER

MARK AND CUT OPENINGS FOR AIR INLET AND OUTLET. CAREFULLY DRILL HOLES FOR (4) 5/16" MOUNTING BOLTS. PLACE AIR CONDITIONER AND HAND START ALL BOLTS USING THE SHORTEST BOLTS THAT FIT YOUR WALL THICKNESS. USE BLUE LOCKTITE OR SIMILAR THREADLOCK (NOT SUPPLIED). TIGHTEN ALL BOLTS EVENLY TO COMPRESS THE GASKET FROM 3/8" TO APPROXIMATELY 1/4". OVERCOMPRESSING THE GASKET CAN BEND THE WALL OR AIR CONDITIONER CAUSING LEAKS.

IF CONSOLE IS USED BE SURE TO MAINTAIN SEPARATION BETWEEN THE AIR INLET AND OUTLET.

CAUTION: IF CONSOLE IS NOT USED ENSURE THAT THE OUTLET FINGER GUARD IS IN PLACE. CALL VISIONAIRE FOR A FREE REPLACEMENT FINGER GUARD IF IT IS MISSING OR DAMAGED.

