



**MODEL 47-7060-1340H DD:** A/C HEAT FRESH AIR 12V  
**MODEL 47-7060-1340V DD:** A/C HEAT FRESH AIR 12V  
**MODEL 47-7060-2340H DD:** A/C HEAT FRESH AIR 24V  
**MODEL 47-7060-2340V DD:** A/C HEAT FRESH AIR 24V

ITEM	DESCRIPTION
1	RELAY - CLUTCH
2	RELAY - POWER
3	CIRCUIT BREAKER - A/C HEATER
4	CIRCUIT BREAKER - CONDENSER
5	RELAY - CONDENSER FAN
6	HI - LOW PRESSURE SWITCH
7	DIN CONNECTOR - HYD. MOTOR

**NOTE:**

- 1) Chasis ground. Ground strap may be required.
- 2) Connect Orange / White wire to a fused ACC circuit or other control circuit that opens when the engine is turned off.

**CAUTION:** Do not connect this wire directly to Battery Power.

**VISIONAIRE, INC.**  
 MANUFACTURER AND DISTRIBUTOR OF HEATERS AND AIR CONDITIONERS FOR HEAVY EQUIPMENT

1502 109th STREET  
 GRAND PRAIRE, TEXAS 75050

972-647-1056      www.visionaire-inc.com

DRAWN	NAME	DATE	DOCUMENT NO:
ENG APPR.	CNH	2/11/13	<b>90-7060-006</b>
	CNH	2/11/13	