



**RELAY PANEL**

**ENTRANCE PANEL**

**CONTROL CIRCUIT BREAKER**  
 12V 15AMP  
 24V 10AMP

**MAIN CIRCUIT BREAKER**  
 12V 50AMP  
 24V 30AMP

**THERMOSTAT**   **CONDENSER FAN RELAY**   **CLUTCH RELAY**   **HIGH FAN RELAY**

**OPTIONAL HYD ENABLE**   **HEAT TRIGGER OPTION**   **CLUTCH GREEN**   **PRESSURIZER RED/WHITE**

**HIGH PRESSURE SWITCH**

**LOW PRESSURE SWITCH**

**BLOWER MOTOR**

**HEATER VALVE SOLENIOD**

**CONDENSER FAN**

**CONTROL PANEL**

**FAN**   **MODE**   **HEAT**   **PRESSURIZER**

**OPTIONAL HYD. ENABLE** USE THIS TERMINAL TO OPERATE AUXILIARY HYDRAULIC OR "IDLE UP" CONTROL. TERMINAL IS ENERGIZED WHEN MODE SWITCH IS ON "A/C."  
**DO NOT EXCEED 2A LOAD**

**HEAT TRIGGER OPTION** USE THIS TERMINAL TO SIGNAL AN AUXILIARY WATER PUMP RELAY. TERMINAL IS ENERGIZED WHEN "HEAT" SWITCH IS ON.  
**DO NOT EXCEED 2A LOAD**

**MODEL 47-7070-10XX:** 7070 SERIES A/C & HEAT AND A/C ONLY 12V  
**MODEL 47-7070-20XX:** 7070 SERIES A/C & HEAT AND A/C ONLY 24V

**VISIONAIRE, INC.**  
 MANUFACTURER AND DISTRIBUTOR OF HEATERS AND AIR CONDITIONERS FOR HEAVY EQUIPMENT  
 1502 109th STREET  
 GRAND PRAIRE, TEXAS 75050  
 972-647-1056   www.visionaire-inc.com

DRAWN	NAME	DATE	DOCUMENT NO:
ENG APPR.			90-7070-002